



Install underfloor conduits approximately 1" beneath the floor insulation as shown.